



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	KPNT1 001	1	PUSH NUT
2	PMRAM-33NP2E S04	1	CABINET
3	PMRAC-19SH4 S01	1	THERMISTOR (OUTSIDE TEMPERATURE)
5	PMRAC-25NH4 S14	1	SUPPORT (FAN MOTOR)
6	PMRAM-72Q8 S03	1	THERMISTOR (OH)
7	PMRAC-51CA1 908	1	NET
8	PMRAC-VX13CGT S01	1	TOP COVER
9	PMRAC-63CA1 S02	1	TERMINAL BOARD (2P)
10	PMRAC-SX10CB S04	1	OVERLOAD RELAY COVER
11	PMRAC-VX13CET S02	1	FAN MOTOR
12	PMRAC-VX13CET S04	1	TERMINAL BOARD (3P)
13	PMRAC-VX10CJ S04	1	D-GRILL
14	PMRAC-X10CZ S05	1	PROPELLER FAN
15	PMRAC-X13CX 902	1	VALVE 2S
16	PMRAM-33NP2E S05	1	REACTOR
17	PMRAM-33NP2E S06	1	ELECTRICAL EXPANSION COIL (R)
18	PMRAM-33NP2E S07	1	ELECTRICAL EXPANSION COIL (W)
19	PMRAM-33NP2E S08	1	EXPANSION VALVE
20	PMRAM-33NP2B S06	1	COIL (REVERSING VALVE)
21	PMRAM-33NP2B S07	1	REVERSING VALVE
22	PMRAM-33NP2E S10	1	THERMISTOR-V-N
23	PMRAM-33NP2E S09	1	THERMISTOR-V-W
24	PMRAM-35QH5 S04	1	STRAINER (COND)
25	PMRAM-40NP2E S01	1	P.W.B. (MAIN)
26	PMRAM-40NP2E S02	1	P,W,B (INVERTER)
27	PMRAM-33NP2E S03	1	COMPRESSOR
28	PMRAM-40NP2B S04	1	STRAINER (PIPE)
29	PMRAM-40QH5 905	1	SV COVER
30	PMRAM-40QH5 908	1	STRAINER (COND 1)
31	PMRAM-40QH5 909	1	STRAINER (COND 2)
32	PMRAM-40QH5 913	1	STRAINER (ST-PIPE-AS-1)
33	PMRAM-40QH5 914	1	STRAINER (ST-PIPE-AS-2)
34	PMRAM-40QH5 S03	1	SIDE PLATE (R)
35	PMRAM-40QH5 S10	1	CONDENSER
36	PMRAM-40QH5 S11	1	THERMISTOR (DEFROST)
37	PMRAS-51CHA1 R15	1	THERMISTOR SUPPORT
38	PMSMARTY235M 902	1	VALVE 3S
39	RAC-2226H 805	1	COMPRESSOR RUBBER