



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	KPNT1 001	9	PUSH NUT
2	PMRAC-30MH1 S05	1	TOP COVER
3	PMRAC-25NH4 S09	1	OVERHEAT THERMISTOR SUPPORT
4	PMRAC-63CA1 S02	1	TERMINAL BOARD (2P)
5	PMRAC-70YHA 908	1	SIDE PLATE L
6	PMRAC-70YHA 916	1	NET COVER
7	PMRAC-70NPD S05	1	D-GRILL
8	PMRAC-70YHA S07	1	PROPELLER FAN
9	PMRAC-70YHA S12	1	SUPPORT (FAN MOTOR)
10	PMRAC-70YHA S13	1	THERMISTOR (DEFROST)
11	PMRAC-VX13CET S04	4	TERMINAL BOARD (3P)
12	PMRAC-X13CX 902	4	VALVE (2S)
13	PMRAM-33NP2E S05	1	REACTOR
14	PMRAM-33NP2B S06	1	COIL (REVERSING VALVE)
15	PMRAM-33NP2B S07	1	REVERSING VALVE
16	PMRAM-33NP2E S08	3	EXPANSION VALVE
17	PMRAM-53NP2B S08	1	EXPANSION VALVE COIL (W)
18	PMRAM-53NP2B S09	1	EXPANSION VALVE COIL (R)
19	PMRAM-53NP2B S10	1	FAN MOTOR
20	PMRAM-53NP3B S05	1	EXPANSION VALVE COIL (B)
21	PMRAM-65QH4 S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
22	PMRAM-70NYP4E S04	1	STRAINER (CO-PIPE-AS 1)
23	PMRAC-70NPD S04	1	CABINET
24	PMRAM-70NYP4E S03	1	COMPRESSOR
25	PMRAM-70NYP4E S01	1	P.W.B. (MAIN)
26	PMRAM-70NYP4E S02	1	P.W.B. (INVERTER)
27	PMRAM-70NP4B S03	1	EXPANSION VALVE COIL (BC)
28	PMRAM-90NYP5E S04	1	EXPANSION VALVE (ATW)
29	PMRAM-72Q8 S03	1	THERMISTOR (OH)

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
30	PMRAM-70NYP4E S05	1	STRAINER (ST-PIPE-AS)
31	PMRAM-72QH5 913	1	SV-COVER
32	PMRAM-72QH5 918	1	VALVE 4S
33	PMRAM-70NPD S02	1	CONDENSER
34	PMRAM-72QH5 S14	1	SIDE PLATE R
35	PMRAM-70NP4E S03	1	THERMISTOR-V-W
36	PMRAM-70NP4E S04	1	THERMISTOR-V-N
37	PMRAM-72QH5 S20	1	SUPPORT (DEF-THERMISTOR)
38	PMSMARTY235M 902	3	VALVE (3S)
39	RAC-2226H 805	1	COMPRESSOR RUBBER
40	PMRAM-90NYP5B S05	2	EXPANSION VALVE (ATW)
41	PMRAM-70NYP4E S06	1	CHECK-VALVE-AS (ATW)
42	PMRAM-70NYP4E S07	1	CHECK-VALVE-AS (ATA)
43	PMRAM-90NYP5B S06	1	EXPANSION VALVE COIL (ATW)
44	PMRAM-90NYP5B S07	1	EXPANSION VALVE COIL (ATA)
45	PMRAM-90NYP5E S03	1	PWB (RELAY)