



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	KPNT1 001	6	PUSH NUT
2	PMRAC-25NH4 910	1	OVERLOAD RELAY COVER
3	PMRAC-25NH4 S09	1	OVERHEAT THERMISTOR SUPPORT
4	PMRAC-63CA1 S02	1	TERMINAL BOARD (2P)
5	PMRAC-70YHA S06	1	NET
6	PMRAC-80YHA S14	1	THERMISTOR (OH)
7	PMRAC-S18CPA S02	1	REVERSING VALVE
8	PMRAC-VX13CET S04	5	TERMINAL BOARD (3P)
9	PMRAC-X18CD S04	1	REACTOR
10	PMRAM-65QH4 S07	1	THERMISTOR SUPPORT
11	PMRAM-90NP5E S08	1	CABINET
12	PMRAM-90NP5A S03	1	PROPELLER FAN
13	PMRAM-90NYP5E S01	1	P.W.B (MAIN)
14	PMRAM-90NYP5E S02	1	P.W.B. (INVERTER)
15	PMRAM-33NP2E S07	1	EXPANSION VALVE COIL (W)
16	PMRAM-33NP2E S06	1	EXPANSION VALVE COIL (R)
17	PMRAM-68NP3B S03	1	EXPANSION VALVE COIL (B)
18	PMRAM-70NP4B S03	1	EXPANSION VALVE COIL (BC)
19	PMRAM-90NP5E S07	1	EXPANSION VALVE COIL (Y)
20	PMRAM-90NP5B S08	1	FAN MOTOR
21	PMRAM-90NP5B S09	1	MG-COIL (REVERSING VALVE)
22	PMRAM-90NP5B S10	1	THERMISTOR (DEFROST)
23	PMRAM-90NP5B S11	1	THERMISTOR (OUTSIDE TEMPERATURE)
24	PMRAM-90NP5E S05	1	THERMISTOR-PIPE (W)
25	PMRAM-90NP5E S06	1	THERMISTOR-PIPE (N)
26	PMRAM-33NP2E S08	4	EXPANSION VALVE
27	PMRAM-90NP5E S03	1	COMPRESSOR
28	PMRAM-90NP5E S04	1	CONDENSER
29	PMRAM-90QH5 905	1	D-GRILL-AS (INCL. MOUTH RING)