



*2 SOME MODELS NOT NEED TO INSTALL THE CIRCUITS IN DASH DOT.

*3 F1 CURRENT VALUE BE DIFFERENT FOR DIFFERENT MODELS.